

## Description

The ISL6298EVAL2 provides a complete platform for the evaluation of the ISL6298-2CR4. The on board 9-bit DIP switch facilitates programming charging current, setting EN input, battery thermal status, and so on. The four jumpers can set up input source selection, USB mode selection, and can be used to make other necessary connections.

Assembled in the center, the components constitute a complete charger solution, demonstrating the space saving advantage of the ISL6298 in limited space applications.

LEDs connected to FAULT and STATUS pins will indicate the normal charging status or fault condition.

On board jumpers and a DIP switch accommodate different operation conditions for the charger.


## Ordering Information

| PART #       | DESCRIPTION                           |
|--------------|---------------------------------------|
| ISL6298EVAL2 | Evaluation Board for the ISL6298-2CR4 |

## Features:

- 9-bit DIP switch for conveniently setting up charging current, battery thermal status, EN input, and so on
- Different jumpers for input source selection, USB mode selection, and the convenience of current measurement
- Exposed soldering pads connected to STATUS, FAULT, TIME, EN, V2P8, IMIN and TEMP functional pins to accommodate experimental testing that need extra connections to those pins
- Board size 3.5 x 2.5 square inches for the convenience of evaluation
- Eight thermal vias in the thermal pad simulating the customers' thermal enhanced environment

## Pinout



## What is inside

The Evaluation Kit contains:

- ISL6298EVAL2 board
- The ISL6298 Data Sheet
- This ISL6298EVAL2 Application Note

## What is needed

The following instruments will be needed to perform testing:


- Power supplies:
  - 1 PS1: DC 20V/5A,
  - 2 PS2: DC (sinks current) 20V/5A, such as Agilent 6654A)
- Electronic load: 20V/5A
- Multimeters
- Function generator
- Oscilloscope
- Cables and wires

## Quick Setup Guide

*Step 1: Switch on bit 4 and bit 7 of the Dip-switch. Leave all other bits off, (See Figure 1.)*

### DO NOT APPLY POWER UNTIL STEP 6

- Step 2: Connect 5V on VIN.*
- Step 3: Connect 3.7V on VBAT.*
- Step 4: Connect 500mA electronic load on VBAT.*
- Step 5: Verify that no shunts across all jumpers.*
- Step 6: Turn on Power Supplies and electronic load.*
- Step 7: Green LED should be on, indicating normal charging operation.*
- Step 8: If current meter is in series with VIN, it shall read 250mA as the charging current.*



**FIGURE 1. INITIAL DIP SWITCH SETTINGS**

## DIP Switch Settings

A 9-bit DIP switch is provided to set up voltage, current reference, end-of-charge (EOC) current, and so on. The functionality of the bits are described in Table 1.

**TABLE 1. DIP SWITCH PIN DESCRIPTIONS**

| BIT | DESCRIPTION            | ON                 | OFF                                      | REMARK                            |
|-----|------------------------|--------------------|------------------------------------------|-----------------------------------|
| 1   | Adjustable TIMEOUT     | 5 hours<br>50 mins | 3 hours<br>30 mins                       |                                   |
| 2   | TIMEOUT disable/enable | TIMEOUT disabled   | TIMEOUT enabled                          |                                   |
| 3   | Charger enable/disable | Charger disabled   | Charger enabled                          |                                   |
| 4   | IREF setting 1         | Add 125mA          | I <sub>CHG</sub> =125mA<br>When both off |                                   |
| 5   | IREF setting 2         | Add 250mA          |                                          |                                   |
| 6   | IMIN setting           | 25mA               | 12.5mA                                   |                                   |
| 7   | TEMP normal            | Normal             |                                          | All off simulates battery removal |
| 8   | TEMP high              | Too hot            |                                          |                                   |
| 9   | TEMP low               | Too cold           |                                          |                                   |

**TABLE 2. JUMPER SETTINGS**

| JUMPER | POSITION         | FUNCTION                                                       |
|--------|------------------|----------------------------------------------------------------|
| JP1    | USB TO VIN       | USB input selected                                             |
|        | WALL CUBE TO VIN | Wall adapter input selected                                    |
| JP2    | Shunt Installed  | Connect VBAT pin to battery<br>Current meter can replace shunt |
| JP3    | shunt installed  | Battery attached to Thermistor at J2                           |
|        | not installed    | Default                                                        |
| JP4    | IREF and V2P8    | Setting USB 255mA mode                                         |
|        | IREF and GND     | Setting USB 100mA mode                                         |

### Initial Board Jumper Positioning (Refer to Figure 3)

**JP1** - Selects the VIN pin to be connected to either a wall adapter, or to a USB connector. If the J1 connector is being used, a shunt must be installed across 'WALL CUBE TO VIN', or if the J3 (USB) connector is being used, a shunt must be installed across 'USB TO VIN'. J1, J3 and JP1 can be ignored if the power supply is connected directly to the VIN test point, which is directly connected to the VIN pin of the IC. A current meter, to measure the input current, can replace the shunt mentioned above.

**JP2** - Can connect the VBAT pin to the battery. If the J2 connector is being used, a shunt must be installed across JP2. In this case, a current meter can also replace the shunt to measure the VBAT current.

**JP3** - Can connect the TEMP pin to the battery. Usually no shunt is needed for JP3, as the Eval board can simulate various battery thermal conditions. Only when a battery with an attached thermistor is applied on J2 does it become necessary to install a shunt across JP3, simultaneously turning off bits 7, 8, and 9 on the DIP switch.

**JP4** - Selects USB modes; a shunt across IREF and V2P8 will set USB 255mA mode, a shunt across IREF and GND will set USB 100mA mode. When the charge current is programmed by the resistors connected to IREF pin, no shunt should be installed on JP4.




FIGURE 2. CONNECTION OF INSTRUMENTS

# Board Layout Information

## Schematics of PCB board





FIGURE 3. BOARD LAYOUT INFORMATION SCHEMATIC

## Application Note 1172


**TABLE 3. ISL6298EVAL2 BILL OF MATERIALS**

| ITEM | QUANTITY | REFERENCE                               | PART DESCRIPTION                   | PCB FOOTPRINT     | PART NUMBER     | VENDOR   |
|------|----------|-----------------------------------------|------------------------------------|-------------------|-----------------|----------|
| 1    | 1        | C1                                      | 1 $\mu$ F, 6.3V, X5R ceramic cap   | 0603              | 0603X105K6R3    | Walsin   |
| 2    | 1        | C2                                      | 10 $\mu$ F/6.3V, Tantalum Cap      | 2.05 x 1.3 x 1.2  | TAJR106M006     | AVX      |
| 3    | 1        | C3                                      | 15nF/16V, X7R ceramic cap          | 0402              | C1005X7R1C153K  | TDK      |
| 4    | 1        | C4                                      | 0.1 $\mu$ F/16V, Y5V ceramic cap   | 0402              | C1005Y5V1C104ZT | TDK      |
| 5    | 1        | C5                                      | 10nF/16V, X7R Ceramic cap          | 0805              | C1005X7R1C103K  | TDK      |
| 6    | 1        | C6                                      | 10 $\mu$ F/16V, Tantalum Cap       | 3.2 x1.6 x 1.6    | TAJA106M016     | AVX      |
| 7    | 1        | D1                                      | Green LED                          | 0805              | 67-1553-1-ND    | DigiKey  |
| 8    | 1        | D2                                      | Red LED                            | 0805              | 67-1552-1-ND    | DigiKey  |
| 9    | 2        | R1, R2                                  | 1K, 5%                             | 0603              |                 | Various  |
| 10   | 1        | R3                                      | 10K, 1%                            | 0603              |                 | Various  |
| 11   | 2        | R4, R5                                  | 160K, 1%                           | 0603              |                 | Various  |
| 12   | 1        | R6                                      | 160K, 1%                           | 0805              |                 | Various  |
| 13   | 1        | R7                                      | 80K, 1%                            | 0805              |                 | Various  |
| 14   | 1        | R8                                      | 160K, 1%                           | 0805              |                 | Various  |
| 15   | 1        | R9                                      | 5K, 1%                             | 0805              |                 | Various  |
| 16   | 1        | R10                                     | 500, 1%                            | 0805              |                 | Various  |
| 17   | 1        | R11                                     | 18K, 1%                            | 0805              |                 | Various  |
| 18   | 1        | J1                                      | 2.54mm Male Header, 2 ckt (R/A)    |                   | A23879-ND       | DigiKey  |
| 19   | 1        | J2                                      | 2.54mm Male Header, 3 ckt (R/A)    |                   | A23880-ND       | DigiKey  |
| 20   | 2        | JP1, JP4                                | 2.54mm Male Header, 3ckt           |                   | WM6403-ND       | DigiKey  |
| 21   | 2        | JP2, JP3                                | 2.54mm Male Header, 2 ckt          |                   | WM6402-ND       | DigiKey  |
| 22   | 1        | J3                                      | USB receptacle, B type             |                   | 787780-1-ND     | DigiKey  |
| 23   | 1        | SW1                                     | DIP Switch, 9 Pos, SMT             |                   | CKN1323-ND      | DigiKey  |
| 24   | 1        | U1                                      | Single-Cell Li-ion Battery Charger | 16-pin, 4 x 4 QFN | ISL6298         | Intersil |
| 25   | 6        | VIN, VBAT,<br>TIME, GND1,<br>GND2, GND3 | Test Point                         |                   | 5002K-ND        | DigiKey  |


PCB Layout




SILK SCREEN LAYER




INTERNAL (LAYER 2, GND)



BOTTOM (LAYER 4, GND)



TOP (LAYER 1, SIGNAL)



INTERNAL (LAYER 3, FLOATING)

Intersil Corporation reserves the right to make changes in circuit design, software and/or specifications at any time without notice. Accordingly, the reader is cautioned to verify that the Application Note or Technical Brief is current before proceeding.

For information regarding Intersil Corporation and its products, see [www.intersil.com](http://www.intersil.com)