

# DOOR MOUNTING FOR UL508 DISCONNECT SWITCHES

**SWITCH REF.**

<b>16A to 40A</b>	<b>63A to 80A</b>
RD16-3-508	RD63-3-508
RD25-3-508	RD80-3-508
RD40-3-508	

3.15 in / 80 mm

3.15 in / 80 mm

⚠ Switch must be turned  
L'interrupteur doit être retourné

**STEP 1**

DOOR-508

Dual dimensions / Double dimensions / Doble dimensiones

in/mm / in/mm / in/mm

13.3 lb-in / 1,5 Nm / Pozidriv 2

OR / OU

13.3 lb-in / 1,5 Nm

0.03 to 0.15 in / 0.8 à 3 mm

90°

ON

OFF

Type 1, 3R, 4, 4X, 12

⓪-O-OFF

**STEP 2**

⓪-O-OFF

Click!

2

1

**STEP 3**

Click!

2

1

CONFIGURATION	
SWITCH	Position
RD16-3-508 - RD25-3-508 RD40-3-508 - RD63-3-508 - RD80-3-508	1
RD16-3-508 + POLE-16 RD25-3-508 + POLE-25 RD40-3-508 + POLE-40	2

1

2

Click!

**⚠ DANGER** / **⚠ PELIGRO** / **⚠ TENSION ALTA**

This equipment must be installed and serviced only by qualified personnel. Turn off all power supplying this equipment before working on or inside equipment. Disconnect the main power supply and lock out the main power supply. Failure to follow these instructions will result in death or serious injury.

Este equipo debe ser instalado y mantenido solo por personal cualificado. Desconecte el equipo antes de realizar trabajos de mantenimiento o dentro del equipo. Desconecte la alimentación principal y asegure la alimentación principal. No opere el equipo con la alimentación principal conectada. El no seguir estas instrucciones puede resultar en la muerte o lesiones graves.

⚠ TENSION ALTA / PELIGRO / TENSÃO ALTA

Este equipamento deve ser instalado e mantido apenas por pessoal qualificado. Desconecte o equipamento antes de realizar trabalhos de manutenção ou dentro do equipamento. Desconecte a alimentação principal e bloqueie a alimentação principal. Não opere o equipamento com a alimentação principal conectada. O não seguir estas instruções pode resultar em morte ou lesões graves.



541576A